



Raleigh M20 Seat Cushion Replacement

This guide will show users how to remove a ruined seat cushion from their seat post and fit a new seat cushion onto their post.

Written By: Dante Bozzini



INTRODUCTION

This guide will be an overview of how to remove and replace a seat cushion. The seat post must be removed from the bicycle frame before a new seat cushion can be added.



TOOLS:

- [64 Bit Driver Kit](#) (1)



PARTS:

- [Seat Cushion](#) (1)

Step 1 — Seat Cushion



- Remove the seat by loosening the seat clamp (marked in the picture). Loosen the seat clamp by pulling the black lever away from the frame and then by rotating it counter-clockwise.

☑ Stand on the right side of the bike while loosening the lever, be sure the bike isn't upside-down.

Step 2



- Hold the seat tight, and pull up on the seat slowly and firmly to remove it from the frame. Now you are ready to remove your seat cushion from your seat post.

Step 3



- Unscrew the bolt that holds the seat cushion itself to the seat post by using an Allen wrench to turn the bolt in a counter-clockwise direction.

Step 4



- Once you have successfully loosen the bolt, pull the seat post free of both the seat cushion and the two riders that sit on the cushion's rails.
- You should have two separate riders, as shown in the middle picture. Pull both the riders off of the cushion's rails.
- You have successfully removed your seat cushion from your bicycle frame. Congratulations!

To reassemble your device and install the new seat cushion, follow these instructions in reverse order with the new seat cushion instead of the old one.